

SECTION 02190 - PRESERVATIVE TREATMENT OF LUMBER

(Follow all instructions. If there are no instructions above a subsection, paragraph, sentence, or bullet, then include them in the project. The specifications may be modified to include project specific specifications, but all additions, deletions, or modifications must be sent to the ODOT Technical Resource and Senior Specifications Engineer for review and approval.)

Comply with Section 02190 of the Standard Specifications modified as follows:

02190.20 Drying Time - Replace this subsection with the following subsection:

02190.20 Drying After Treatment - When using waterborne preservatives, as defined in AWWA P5, dry items according to AWWA T1, Section 7.

During the drying period and until the treated items are installed on the Project, separate each layer of treated items using spacers that are at least 1/2 inch thick.

The maximum moisture content shall be 19 percent prior to installation.

Collect all spacers and other treated wood waste from the construction site and dispose of them according to 00290.20.